


MAXI MIX KARIŞTIRICI
MAXI MIX AGITATOR
AGITADOR MAXIMIX

0510150010 - 0510150012 - 0510150015 - 0510150018
0510150020 - 0510150025 - 0510150030 - 0510150050



NO	KOD - CODE - CÓDIGO
1	05101507
2A	08060010
2B	08060012
2C	08060015
2D	08060018
2E	08060020
2F	08060025
2G	08060030
2H	08060050
3	OR3001500
4	04001121
5	05101506
6	04001452
7	OR5334700
8	C466540
9	05101505
10	05101504
11	V4213YSBS
12	OR3532817
13	05101503
14	05101502
15	05101501
16A	0510150810
16B	0510150812
16C	0510150815
16D	0510150818
16E	0510150820
16F	0510150825
16G	0510150830
16H	0510150850
17	05101500